

FARROW CUPBOARD

Thank you for purchasing this Farrow Cupboard. Please read the instructions carefully before use to ensure safe and satisfactory operation of this product.



Pre-assembly preparation

Please ensure instructions are read in full before attempting to assemble this product.

People to assemble



Tools required



Please check the pack contents before attempting to assemble this product. A full checklist of components is given in this leaflet. If any components are missing, please contact the retailer from whom you bought this product.

This product is **HEAVY**, it should be assembled as near as possible to the point of use. **TAKE CARE WHEN LIFTING** to avoid personal injury and (or) damage to the product.

This product takes approximately **50 MINUTES** to assemble with **2 PEOPLE**.

The fittings pack contains **SMALL ITEMS** which should be **KEPT AWAY FROM YOUNG CHILDREN**.

Read this leaflet in full before commencing assembly.

PLEASE KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE

Fittings and parts checklist


| Parts checklist | | | | | | | | |
|-----------------|--------------------------|-----|---|--------------------------|-----|--|--|--|
| 1 | Left leg x1 | | | | | | | |
| 2 | Right leg ×1 | | | | | | | |
| 3 | Top shelf x1 | 30 | 4 | Middle shelf #1 x1 | 330 | | | |
| 5 | Middle shelf #2 x1 | 350 | 6 | Top rail x1 | | | | |
| 7 | Cupboard x1 | | | | | | | |

| Fitting checklist | | | | | | | | |
|-------------------|-------------------------------|---|---|-------------------------------------|--|--|--|--|
| Α | Long bolt x14 M6x65mm | | В | Short bolt x2 M6x15mm | | | | |
| С | Half-moon washer x14 | | D | Flat washer ×14 M6-Ø12mm | | | | |
| Е | Allen key #5 x1 | | H | Allen key #4 x1 | | | | |
| G | Wall bracket x2 L78.5mm | 0 | Н | Small flat washer x2 Ø9x1.0mm | | | | |
| I | Wood dowel x8 Ø8x30mm | | J | Middle bolt x8 M6x30mm | | | | |
| K | Felt pad x4 | | | | | | | |

Step 1


With 2 people, carefully place the cupboard (Part 7) on a soft, flat surface near where the unit will be used. Remove the adjustable shelves as shown below.






Step 2

Carefully place the left leg (Part 1) on a soft, flat surface near where the unit will be used. Locate the cupboard (Part 7) using the wood dowel (Part I), as shown below.




Step 3

Secure the cupboard (Part 7) to the left leg (Part 1) using the middle bolt (Part J) and the Allen key (Part F), as shown below.




Step 4

Carefully locate the top shelf (Part 3) and middle shelves (Part 4 & 5) then secure using the long bolt (Part A), flat washer (Part D), Half-moon washer (Part C) and the Allen key (Part E), as shown below.




Step 5

Locate the top rail (Part 6) then secure using the long bolt (Part A), flat washer (Part D), Half-moon washer (Part C) and the Allen key (Part E), as shown below.




Step 6

Locate the right leg (Part 2) then secure using the long bolt (Part A), flat washer (Part D), Half-moon washer (Part C) and the Allen key (Part E), as shown below.




Step 7

Secure the cupboard (Part 7) with the right leg (Part 2) using the middle bolt (Part J) and the Allen key (Part F), as shown below.




Step 8


With 2 people, carefully turn the product over and place in position. Do not drag the product when moving, must be lifted to prevent damaging the legs!



Step 9


Fix the wall brackets (Part G) to the top shelf (Part 3) using the short bolt (Part B) and the Allen key (Part F) as shown below.






Wall fixing - if in doubt seek professional advice

Please ensure to use the correct size wall plug when installing the wall bracket to a wall. If your wall is cavity construction or wood you may need to seek appropriate wall fixings.




Wood

If fixing to wood make sure that it isn't chipboard as screws can easily pull away from the core structure.



Brick or Masonry

Use an appropriate wall plug provided you are sure your wall is sound.




Cavity wall

Special toggle wall plugs are needed. Seek expert advice.

Step 10

Adjust the wall brackets (Part G) to be flat against the wall and use a pencil (not included) to accurately mark the position of the screw holes onto the wall. Now carefully move the product away from the wall to create


space for drilling.



Step 11


Before drilling, ensure the size of holes will be correct to fit the wall plug (not included). Drill the hole according to the marked position and push the wall plug (not included) into position as shown below.

Warning: Ensure the area to be drilled is free from hidden electrical wires, water and gas pipes.




Step 12

Secure the two wall brackets (Part G) to the wall using the small flat washers (Part H) and screws (not included). Tighten with the screwdriver (not included).





WARNING!
In order to prevent
overturning, this product
must be used with the wall
attachment device provided.



Step 13

Adjust the shelf supports into the desired height if need. After, re-locate the shelves onto shelf supports.





Care and Maintenance

Wood furniture

- Wood displays different grain patterns depending on which way they cut for example, the 'medullary rays' which can appear is a mark of good quality timber these are just characteristics of the natural beauty of the wood. Some furniture is also deliberately aged and rustic.
- Wood veneers also allow distinctive patterns to be created on flat surfaces, such as table tops and drawer fronts by the way the slivers are arranged.
- All timber surfaces will change colour and mellow over time. New furniture will initially vary in shade from items that have been previously purchased.

How to care for your wood furniture

- Furniture with a hard lacquer, wax polish or painted surface should be dusted with a dry cloth.
- Spray polishes are best avoided as they contain silicones which may spoil the furniture's surface by building up over time.
- Make sure all surfaces are protected from heat and liquids by mats and coasters. Wipe up spills immediately and ensure that a mat or pad is placed under paper if you are writing.
- Our furniture will endure most temperatures in the home but it is best to avoid placing furniture next to heat sources such as radiators or fires. Be particularly careful with solid wood as the lack of humidity caused by central heating can cause damage such as warping.

Safety instructions

- Never drag furniture when moving it, always lift it.
- Do not sit or stand upon this product.
- Maximum Load Capacity: 15kg for each shelf.
- Periodically check all fixings to ensure none have come loose and re-tighten where necessary.
- Please take care when handling or moving the furniture, careless handling may cause damage or injury.
- Furniture can be dangerous if incorrectly installed. Assembly should be carried out by a competent person. No liability will be accepted for damage or injury caused by incorrectly installed or assembled furniture.
- It is recommended that before moving heavy objects to a new location they are completely disassembled to avoid personal injury or damage to the furniture. Please be careful to retain all fittings when doing this.

PLEASE READ!

This veneered product has a natural open grain finish. Please read the care guide thoroughly. We recommend using mats and wiping up spilled liquids immediately.

Avoid placing plant pots or vases without waterproof mats to prolong the life of this product.

Experiencing problems with your new product?

Before calling customer service, please have your item's batch code ready.

You can find the batch code on the back or bottom of your product as below shown.

(example batch code: 200510)

