



Swivel V2 dining table

Thank you for purchasing this Swivel V2 dining table. Please read the instructions carefully before use to ensure safe and satisfactory operation of this product.




Pre-assembly preparation

Please ensure instructions are read in full before attempting to assemble this product.

People to assemble



Tools required



Please check the pack contents before attempting to assemble this product. A full checklist of components is given in this leaflet. If any components are missing, please contact the retailer from whom you bought this product.

This product is **HEAVY**, it should be assembled as near as possible to the point of use. **TAKE CARE WHEN LIFTING** to avoid personal injury and (or) damage to the product.








This product takes approximately **20 MINUTES** to assemble with **2 PEOPLE**.

The fittings pack contains **SMALL ITEMS** which should be **KEPT AWAY FROM YOUNG CHILDREN**.

Read this leaflet in full before commencing assembly.

PLEASE KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE


Fittings and parts checklist

A	Table top x 1	
B	Leg x 4	
C	Bolt x 8 M6x60mm	
D	Spring washer x 8 M6-Ø9mm	
E	Flat washer x 8 M6-Ø16mm	
F	Allen key x 1 #4	
G	Felt pad x 4	

Step by step assembly instructions


Step One

With 2 people, carefully place the top upside down on a soft, flat surface that is raised off the floor (for example on another table) near to where the product will be used. Locate and slide into position the legs (part B). Then secure the leg (part B) as shown below using the flat head bolt (part C) with spring washer (part D), flat washer (part E) and allen key (part F).




Step Two

Carefully rotate the box frame clock-wise by 90 degrees as shown below.




Step Three

Locate and slide into position the legs (part B). Then secure the leg (part B) as shown below using the flat head bolt (part C) with spring washer (part D), flat washer (part E) and allen key (part F).



Step Four

Carefully rotate the box frame anticlock-wise by 90 degrees as shown below.




Step Five

With 2 people, carefully hold the legs and both halves of the table top to turn the table over and place in position. Please always hold the box frame or legs when moving table, do NOT catch table top!

If the product will be placed on a hard floor, we advise applying the felt pads (part G) to the bottom of the legs to prevent damage to the floor and the product.

CAUTION!

This is a heavy unit. Carefully hold the legs and both halves of the table top to turn the table over and the table top could hinge open if not held securely when turning.






Warm reminder:

1. When moving the table, to lift the table frame or feet, please do not directly lift the table top.
2. Clear the table before folding it.
3. Turn the desktop to a fixed position before turning it over.

How to extend

Step 1: Carefully clockwise rotate the top panel by 90 degrees as shown below.

Step 2: Open the top as shown as shown below.



PLEASE READ!

This veneered product top has a natural open grain finish. Please read the care guide thoroughly. We recommend using mats and wiping up spilled liquids. Avoid placing plant pots or vases without waterproof mats to prolong the life of this product.

Care and Maintenance

Wood furniture

- Wood displays different grain patterns depending on which way they cut - for example, the 'medullary rays' which can appear as a mark of good quality timber - these are just characteristics of the natural beauty of the wood. Some furniture is also deliberately aged and rustic.
- Wood veneers also allow distinctive patterns to be created on flat surfaces, such as table tops and drawer fronts by the way the slivers are arranged.
- All timber surfaces will change colour and mellow over time. New furniture will initially vary in shade from items that have been previously purchased.

How to care for your wood furniture

- Furniture with a hard lacquer, wax polish or painted surface should be dusted with a dry cloth.
- Spray polishes are best avoided as they contain silicones which may spoil the furniture's surface by building up over time.
- Make sure all surfaces are protected from heat and liquids by mats and coasters. Wipe up spills immediately and ensure that a mat or pad is placed under paper if you are writing.
- Our furniture will endure most temperatures in the home but it is best to avoid placing furniture next to heat sources such as radiators or fires. Be particularly careful with solid wood as the lack of humidity caused by central heating can cause damage such as warping.

Safety Instructions

- Never drag furniture when moving it, always lift it. Please always hold the box frame or legs when lifting table, do NOT catch table top!
- Periodically check all fixings to ensure none have come loose and re-tighten where necessary.
- Please take care when handling or moving the furniture, careless handling may cause damage or injury.
- Furniture can be dangerous if incorrectly installed. Assembly should be carried out by a competent person. No liability will be accepted for damage or injury caused by incorrectly installed or assembled furniture.
- It is recommended that before moving heavy objects to a new location they are completely dis-assembled to avoid personal injury or damage to the furniture. Please be careful to retain all fittings when doing this.

Experiencing problems with your new product?

Before calling customer service, please have your item's batch code ready.

You can find the batch code on the back or bottom of your product as shown below.

(example batch code: I90510)

